

ACTI'SPHERES

CREAM-IN-GEL
043.C10/C2



FACE

GP2026INCOS

EMULSION



OVERVIEW

This emulsion-in-gel formula is built around key functional ingredients selected for both performance and sensory balance. In the emulsion part, Montanov™ 202 acts as a naturally derived O/W emulsifier, ensuring emulsion stability while providing a smooth and creamy skin feel. SAFIC' Care T XG Clear P supports emulsion structuring and stability by improving viscosity and suspension, while maintaining a clear and homogeneous texture. The emollient system, composed of Lipex® SheaSoft TR™ and Lipex® 205, delivers nourishment, softness, and long-lasting comfort, while Lipex® SheaLuxe TR™ enhances spreadability and provides a light, silky after-feel. In the gel part, Sepimax™ Zen builds a fresh and elastic gel network, contributing to lightness, freshness, and excellent rheological stability.

Phase	Trade Name	Supplier	European I.N.C.I. Name	Function	%
A	Demineralized water	/	Aqua	/	61,30
	Glycerin		Glycerin	Humectant	5,00
B	SAFIC' Care T XG Clear P	SAFIC-ALCAN*	Xanthan Gum	Suspensive agent	1,00
C	NatSorb Orange LC211	SENSIENT*	Ethyl Ferulate, Triethyl Citrate, Bixa Orellana Seed Oil, Tocopherol, Helianthus Annuus Seed Oil, CI 75120	Color	1,00
	Montanov™ 202	SEPPIC*	Arachidyl Alcohol, Behenyl Alcohol, Arachidyl Glucoside	O/W emulsifier	3,00
	Protachem™ CS-50	PROTAMEEN*	Cetearyl Alcohol	Consistency agent & co-emulsifier	2,00
	Lipex® SheaSoft TR™	AAK*	Butyrospermum Parkii Butter	Emollient	6,00
	Lipex® 205		Butyrospermum Parkii Butter		6,00
	Lipex® SheaLuxe TR™		Ethyl Oleate, Ethyl Stearate		10,00
D	Amihope™ SB-201	AJINOMOTO*	Silica, Behenyl Alcohol, Stearoyl Glutamic Acid	Sensory enhancer	3,00
E	Plantasens® Vitamin E Natural 50	CLARIANT*	Tocopherol, Helianthus Annus Seed Oil	Anti-oxidant	0,40
	Perfume	/	Parfum	Fragrance	0,30
F	Sharomix™ EG 14	SHARON*	Phenoxyethanol, Ethylhexylglycerin	Preservative	1,00

* Please contact us to know in which country we are supplier of

SAFIC' Care is a trademark of SAFIC-ALCAN

PROCESS

PHASE A : Heat to 80-85°C under stirring.

PHASE B : Pre-mix and add to phase A. Stir for 15 minutes until homogeneous.

PHASE C : Heat to 80-85°C under stirring until homogeneous.

Add phase C to phase AB and stir until homogeneous.

Allow to cool to room temperature.

PHASE D : Add to phase ABC and stir until homogeneous.

PHASE E : Pre-mix and add to phase ABCD.

PHASE F : Add to phase ABCDE and stir until homogeneous.

Adjust pH to 5,5-6,0.



PROPERTIES

APPEARANCE : Yellow cream.

VISCOSITY : 23720 cPs
(Brookfield RVDV-I+, 5 rpm, 1 min, spindle 4).

pH : 5,5-6,0.



ACTI'SPHERES

CREAM-IN-GEL
043.C10/C2



FACE

GP2026INCOS

GEL



OVERVIEW

This emulsion-in-gel formula is built around key functional ingredients selected for both performance and sensory balance. In the emulsion part, Montanov™ 202 acts as a naturally derived O/W emulsifier, ensuring emulsion stability while providing a smooth and creamy skin feel. SAFIC' Care T XG Clear P supports emulsion structuring and stability by improving viscosity and suspension, while maintaining a clear and homogeneous texture. The emollient system, composed of Lipex® SheaSoft TR™ and Lipex® 205, delivers nourishment, softness, and long-lasting comfort, while Lipex® SheaLuxe TR™ enhances spreadability and provides a light, silky after-feel. In the gel part, Sepimax™ Zen builds a fresh and elastic gel network, contributing to lightness, freshness, and excellent rheological stability.

Phase	Trade Name	Supplier	European I.N.C.I. Name	Function	%
A	Demineralized water	/	Aqua	/	92,00
	Glycerin		Glycerin	Humectant	5,00
B	Sepimax™ Zen	SEPPIC*	Polyacrylate Crosspolymer-6	Thickener	2,00
C	Sharomix™ EG 14	SHARON*	Phenoxyethanol, Ethylhexylglycerin	Preservative	1,00

* Please contact us to know in which country we are supplier of

PROCESS

PHASE A : Stir until homogeneous.

PHASE B : Add to phase A and stir until homogeneous.

PHASE C : Add to phase AB and stir until homogeneous.
Adjust pH to 5,5-6,5.



PROPERTIES

APPEARANCE : Transparent gel.

VISCOSITY : 60800 cPs
(Brookfield RVDV-I+, 5 rpm, 1 min, spindle 6).

pH : 5,5-6,5.

