

AQUABURST

BEADS-TO-GEL SERUM

008(2).T3

FACE

GP2026INCOS



OVERVIEW

Experience hydration like never before with our crushable blue serum beads: tiny translucent spheres that gently burst under your fingertips to release a fresh, smoothing serum. Formulated with a hydrating core of Oligo-HA, and Rice PDRN, it delivers intense moisture and supports skin regeneration. The matrix is structured with SAFIC' Care T CK 2 and Cekol® 150 Cellulose Gum, offering a soft, elastic texture that holds shape while remaining easy to apply. SAFIC' Care A Blue Liquid gives the beads their unique blue hue, adding a touch of visual appeal. Perfect for daily use, this playful yet efficient serum format offers a new sensorial approach to hydration with a skin-smoothing finish.

Phase	Trade Name	Supplier	European I.N.C.I. Name	Function	%
A	Demineralized water	/	Aqua	/	90,20
	Glycerin		Glycerin	Humectant	5,00
B	SAFIC' Care T CK 2	SAFIC-ALCAN	Chondrus Crispus Powder	Gelling agent	1,50
	Cekol® 150 Cellulose Gum	NOURYON*	Cellulose gum	Sensory enhancer	0,05
C	Rice PDRN	HYUNDAI BIOLAND*	Aqua, 1,2-Hexanediol, Hydrolyzed DNA, Sodium Phytate	Active	1,00
	Oligo-HA		Hyaluronic Acid		0,20
	SAFIC' Care A Blue Liquid	SAFIC-ALCAN	Genipa Americana Fruit Extract, Glycerin		0,05
D	Sensicare® NAT 2	CHEMIPOL*	Triethyl Citrate, Phenyl Propanol	Preservative	2,00

* Please contact us to know in which country we are supplier of

SAFIC' Care is a trademark of SAFIC-ALCAN

PROCESS

PHASE A : Heat up to 75°C and place under stirring.

PHASE B : Pre-mix then add it to phase A and stir for 15 minutes until homogeneous.

PHASE C : Pre-mix then add it to phase AB and stir until homogeneous.

PHASE D : Add it to phase ABC and stir until homogeneous.

Complement in water and adjust pH to 5,0-6,5.

Use a syringe to put in spherical molds and let cool in the fridge for 1h.

PROPERTIES

APPEARANCE : Transparent blue beads.

VISCOSITY : N/A.

pH : 5,0 - 6,5.