

GLOW, GLOW BABY

RICH MASK
025.N2



FACE

GP2026PL

OVERVIEW

With premium sensory comes premium results! Aristoflex® Eco T is the rheology modifier responsible for the glossy look & premium sensory of this emulsion. Plantasens® Emulsifier HP 49 is the main emulsifier and stabilizes the emulsion with SAFIC' Care E FA 1618 MB. Camelina Oil Lipactive is an active emollient protecting cell structure and Harmonie™ Soft Fluid provides the perfect non-greasy feel. OleoFilm® Green is a film-former which enhances the spreadability. CitroButter™ S provides nourishment. Harmonie™ Luxe 4 Powder helps mitigate any greasiness providing a dry after-feel. Hexcine T Green and A-Leen® 6 work together to well preserve the formula. While Ilumys prevents dark spot formation, PeoGlow targets uneven skin tone to fade the existing ones. PhytoCellTec™ Exosomes delivers a dual exosome action that boosts collagen production and reduces wrinkles, while Quintup™ MB further enhances collagen synthesis.



Phase	Trade Name	Supplier	European I.N.C.I. Name	Function	%
A	Demineralized water	/	Aqua	/	66,70
	Glycerin		Glycerin	Humectant	5,00
B	Aristoflex® Eco T	CLARIANT	Caesalpinia Spinosa Gum, Ammonium AMPS Crosspolymer	Thickener & suspensive agent	1,00
	Plantasens® Emulsifier HP 49		Cetearyl Glucoside, Sorbitan Stearate, Cetearyl Alcohol, Disodium Cetearyl Sulfosuccinate	O/W emulsifier	3,00
C	SAFIC' Care E FA 1618 MB	SAFIC-ALCAN	Cetearyl Alcohol	Consistency agent & co-emulsifier	3,00
	OleoFilm® Green	POLYMEREXPERT - part of SOLABIA GROUP	Hydrogenated Castor Oil/Sebacic Acid Copolymer	Film former	1,00
	Camelina Oil Lipactive	GREENTECH	Camelina Sativa Seed Oil	Emollient	2,00
	CitroButter™ S	P2 SCIENCE	Butyrospermum Parkii Butter, Polycitronellol, Helianthus Annuus Seedcake		2,00
	Harmonie™ Soft Fluid	MOMENTIVE	C9-12 Alkane		5,00
	Harmonie™ Luxe 4 Powder		Silica	Sensory enhancer	2,00
E	Hexcine T Green	MINASOLVE	Ethylhexylglycerin, Tocopherol	Preservative booster	0,20
	A-Leen® 6		1,2-Hexanediol		1,50
	Ilumys (001332)	GREENTECH	Triheptanoin, Zingiber Officinale Root Extract	Active	1,00
	Perfume	/	Parfum	Fragrance	0,80
F	Shiconix Liquid MD(J)	ICHIMARU PHARCOS	Octyldodecyl Myristate, Lithospermum Officinale Root Extract	Natural color	0,30
	PeoGlow		Butylene Glycol, Aqua, Paeonia Albiflora Root Extract		2,00
	Quintup™ MB	CORUM	Glycerin, Aqua, Palmitoyl Pentapeptide-4	Active	1,00
	PhytoCellTec™ Exosomes	MIBELLE BIOCHEMISTRY	Lycium Barbarum Callus Culture Extract, Isomalt, Lecithin, Aqua		0,50
	Demineralized water	/	Aqua	/	2,00

SAFIC' Care is a trademark of SAFIC-ALCAN

GLOW, GLOW BABY

RICH MASK
025.N2



FACE

GP2026PL



OVERVIEW

With premium sensory comes premium results! Aristoflex® Eco T is the rheology modifier responsible for the glossy look & premium sensory of this emulsion. Plantasens® Emulsifier HP 49 is the main emulsifier and stabilizes the emulsion with SAFIC' Care E FA 1618 MB. Camelina Oil Lipactive is an active emollient protecting cell structure and Harmonie™ Soft Fluid provides the perfect non-greasy feel. OleoFilm® Green is a film-former which enhances the spreadability. CitroButter™ S provides nourishment. Harmonie™ Luxe 4 Powder helps mitigate any greasiness providing a dry after-feel. Hexcine T Green and A-Leen® 6 work together to well preserve the formula. While Ilumys prevents dark spot formation, PeoGlow targets uneven skin tone to fade the existing ones. PhytoCellTec™ Exosomes delivers a dual exosome action that boosts collagen production and reduces wrinkles, while Quintup™ MB further enhances collagen synthesis.

PROCESS



PHASE A : Heat up to 75°C under stirring.

PHASE B : Pre-mix then add it to A and stir for at least 10 minutes.

PHASE C : Heat up to 75°C under stirring then add it to AB and stir until homogeneous.

PHASE D : Slowly add to ABC.

Cool down to 40°C.

PHASE E : Stir until homogeneous then add it to ABCD.

PHASE F : Stir until dissolved then add it to ABCDE.

Complement with water, homogenize then adjust pH to 5,5-6,5.

PROPERTIES



APPEARANCE : Pink cream.

VISCOSITY : 89200 cPs
(Brookfield RVDV-I+, 5 rpm,
1 min, spindle 6).

pH : 5,5-6,5.